

Link do produktu: <https://eros.abrakadabra.shop.pl/le-wand-purple-p-61639.html>

le Wand Purple

Cena	276,00 zł
Numer katalogowy	ERO-42-54018870000
Kod producenta	42-54018870000
Kod EAN	4890808278246

Opis produktu

Winner of Cosmopolitan's Sexcellence Award of "Most Powerful Sex Toy," Le Wand Rechargeable Vibrating Massager is guaranteed to deliver intense and sensual pleasure. The luxurious massager has 10 distinctive, rumbly vibration speeds and 20 vibration patterns. Le Wand's sleek design provides focused vibration in the head of the wand. Powerful, penetrating pleasure is granted in the convenience and versatility of a rechargeable wand. Le Wand Rechargeable Vibrating Massager is a complete set that features a body-safe silicone head, flexible neck, convenient travel case, and beautifully giftable packaging. Universal changeable adapters for US, UK, EU, & AU. Soft, seamless silicone & ABS plastic. 10 Vibration speeds & 20 vibration patterns. Soft silicone head & flexible neck. Splash-proof. Rechargeable battery. Includes convenient travel case. Premium Packaging. Materials: body-safe silicone & ABS. Size: 34,0 (H) x 6,2 (D) cm. Diameter: 6,21 cm / 2.45 inch. Neck diameter: 5,0 cm / 1.97 inch. Circumference: 19,5 cm / 7.69 inch. Weight: 1.49 lbs / 674 g. Battery: 2200 mAh. Charging time: 3 hours. Use Time: Up to 3 hours. Max noise level: < 68 dB. Interface: 3 button control. Intensity levels: 10. Vibration modes: 20. Battery Voltage = 7.4V. Motor RPM No loading = 7,400 RPM + / - 10% ("No loading" means the motor is tested without the counterweight, so the motor spins faster). Motor RPM Loaded = 5,800 RPM + / - 10% ("Loaded" means the motor is tested with the counterweight, so the motor spins slower). Is Le Wand Rechargeable Vibrating Massager waterproof? No, it is neither waterproof or splashproof. Do not use it in the shower or a bath. How should I clean Le Wand Rechargeable Vibrating Massager? Use a damp cloth and mild antibacterial soap to wipe the toy down. Make sure the cloth removes all soap residue before you allow the toy to dry. You can also use a sex-toy cleaner directly on the area of use, and finish with a damp cloth. How should I store my Le Wand Rechargeable Vibrating Massager? After cleaning, allow Le Wand Rechargeable Vibrating Massager to air dry. Then, put it into the storage pouch included with the toy and tuck it in your drawer/box of treasures. Is Le Wand Rechargeable Vibrating Massager intended for external or internal use? Le Wand Rechargeable Vibrating Massager is designed to provide stimulation on the outside of the body. Check out our attachment collection to add texture to the vibration or convert it into an internal vibrator. About le Wand Le Wand is a woman-founded premium brand of personal vibrating massagers that bring unparalleled quality to a notoriously sketchy industry. Le Wand originated as one hell of a classic wand (all the power you could want with award-winning design to match) and has now become a full line of best-in-class, heart-pounding, hair-raising toys. Designed with pleasure in mind for all bodies, Le Wand embraces and champions intimacy for all, with powerful, versatile pleasure tools that insist on bringing you to the next level. We're proud to be people's go-to for orgasms they can count on over and over again.