Dane aktualne na dzień: 28-11-2026 08:51

Link do produktu: https://eros.abrakadabra.shop.pl/le-wand-purple-p-61639.html



le Wand Purple

Cena	**276,00 zł**
Dostępność	**Aktualnie niedostępny**
Czas wysyłki	**3 dni**
Numer katalogowy	**ERO-42-54018870000**
Kod producenta	**42-54018870000**
Kod EAN	**4890808278246**

Opis produktu

Winner of Cosmopolitanâ€™s Sexcellence Award of â€śMost Powerful Sex Toy,â€ť Le Wand Rechargeable Vibrating Massager is guaranteed to deliver intense and sensual pleasure. The luxurious massager has 10 distinctive, rumbly vibration speeds and 20 vibration patterns. Le Wandâ€™s sleek design provides focused vibration in the head of the wand. Powerful, penetrating pleasure is granted in the convenience and versatility of a rechargeable wand. Le Wand Rechargeable Vibrating Massager is a complete set that features a body-safe silicone head, flexible neck, convenient travel case, and beautifully giftable packaging.Universal changeable adapters for US, UK, EU, & AUSoft, seamless silicone & ABS plastic10 Vibration speeds & 20 vibration patternsSoft silicone head & flexible neckSplash-proofRechargeable batteryIncludes convenient travel casePremium PackagingMaterials: body-safe silicone & ABSSize:Â 34,0 (H) x 6,2 (D) cmDiameter:Â 6,21 cm / 2.45 inchNeck diameter:Â 5,0 cm / 1.97 inchCircumference:Â 19,5 cm / 7.69 inchWeight:Â 1.49 lbs / 674 gBattery:Â 2200 mAhCharging time:Â 3 hoursUse Time:Â Up to 3 hoursMax noise level:Â < 68 dBInterface:Â 3 button controlIntensity levels:Â 10Vibration modes:Â 20Battery Voltage = 7.4VMotor RPMÂ NoÂ loadingÂ = 7,400RPM + / - 10% ("No loadingâ€ť means the motor is tested without the counterweight, so the motor spins faster)Motor RPM Loaded = 5,800RPM + / - 10% ("Loaded" means the motor is tested with the counterweight, so the motor spins slower)Is Le Wand Rechargeable Vibrating Massager waterproof?No, it is neither waterproof or splashproof. Do not use it in the shower or a bath.How should I clean Le Wand Rechargeable Vibrating Massager?Use a damp cloth and mild antibacterial soap to wipe the toy down. Make sure the cloth removes all soap residue before you allow the toy to dry. You can also use a sex-toy cleaner directly on the area of use, and finish with a damp cloth.How should I store my Le Wand Rechargeable Vibrating Massager?After cleaning, allow Le Wand Rechargeable Vibrating Massager to air dry. Then, put it into the storage pouch included with the toy and tuck it in your drawer/box of treasures.Is Le Wand Rechargeable Vibrating Massager intended for external or internal use?Le Wand Rechargeable Vibrating Massager is designed to provide stimulation on the outside of the body. Check out ourÂ attachment collectionÂ to add texture to the vibration or convert it into an internal vibrator.About le WandLe Wand is a woman-founded premium brand of personal vibrating massagers that bring unparalleled quality to a notoriously sketchy industry. Le Wand originated as one hell of a classic wand (all the power you could want with award-winning design to match) and has now a become a full line of best-in-class, heart-pounding, hair-raising toys. Designed with pleasure in mind for all bodies, Le Wand embraces and champions intimacy for all, with powerful, versatile pleasure tools that insist on bringing you to the next level. Weâ€™re proud to be peopleâ€™s go-to for orgasms they can count on â€” over and over again.